

# David Straz Science Center (DSC)

## DSC 153 Document Camera Instructions for Spring 2019

1. Make sure the **Magnavox DVD/VCR** is plugged into power. (There are two power outlets on the table top with the touch panel.)
2. Make sure the document camera is plugged into power.
3. Plug the video cable coming out of the back of the document camera into the yellow plug on the front of the DVD/VCR.
4. Turn on the DVD/VCR using its power button or the power button on the DVD/VCR remote.
5. Switch on the document camera. Its power switch is located on the left side of the document camera.
6. Plug one of the HDMI cables (**Laptop HDMI** or **Aux HDMI**) into the HDMI port on the back of the DVD/VCR.
7. Use the touch panel to project the HDMI input that you plugged into the DVD/VCR (Laptop HDMI or Aux HDMI)
8. Use the **Source** button on the top of the DVD/VCR remote to make sure the DVD/VCR is on its **L2 (FRONT)** input.

Be sure to turn off the document camera, DVD/VCR, & projection system when you're done using them at the end of class.

Unique solution ID: #1492

Author: Richard LaHue

Last update: 2019-02-07 01:33